LANDSCAPE GARDEN SPEAKER



Excellence in Audio Envirotainment®

Installation Instruction Sheet



Note: This installation instruction is good for all LGS models.

OVALESQUE









LGS100

LGS300

LGS400

Install Garden Speaker base to ground media using proper hardware.
(MOUNTING HARDWARE NOT INCLUDED)






Install Garden
Speaker upper
section onto
base. Connect
speaker wires
and test unit.
Insert mounting
screws supplied
with speaker into
pre-drilled holes
and tighten.




Check all wiring connections and your Landscape Garden Speaker is ready.



17141 Kingsview Avenue, Carson, CA 90746-1207 USA Tel: 310.515.1900 Fax: 310.515.1606





17141 Kingsview Avenue, Carson, CA 90746-1207 USA Tel: 310.515.1900 Fax: 310.515.1606 Web: www.owi-inc.com